

## Assembly Instructions HoloStand



## 1. Parts

- 1 Base plate
- 1 Connecting rod
- 2 Side supports
- 2 Plastic inserts
- 2 Hexagon socket screws, 6 mm
- 2 Hexagon socket screws, 10 mm

## 2. Assembly

The HoloStand is suitable solely for use with a 50" HoloPro™ screen!

Push the ends of the connecting rod into the boreholes in the side supports and secure by tightening up the hexagon socket screws.

Then attach the side supports to the base plate. To do this, lay the side supports and base plate together on their side and insert the M10 screws from underneath, through the base plate and into the side supports and tighten them up.

Now place the stand in an upright position and push the plastic inserts into the side supports from above, taking care to ensure that the grooves in the side supports and the inserts match. Now slide the 50" HoloPro™ screen into place along the guide groove.

As the glass is susceptible to breakage, it should not be inserted too roughly or at an angle.



50"  
HoloPro™

